



www.zyvex.com



Thomas A. Cellucci, Ph.D., MBA
Chief Operating Officer

tcellucci@zyvex.com





ATP Advisory Committee Nanotechnology without the Hype



Overview

- Corporate Overview
- Strategic Thrust
- Products and Capabilities Overview
- Open Discussion



Our Mission

To be the the leading worldwide supplier of tools, products, and services that enable adaptable, affordable, and molecularly precise manufacturing.



Corporate Introduction

- Privately held company
- Founded in 1997
- Located in Richardson, Texas
- Detailed Five-Year Strategic Business and Marketing plans
- Detailed Technology Roadmap
- Aggressive IP strategy
- Extensive list of scientific and business publications





Resources

- Headcount: 52 and increasing
 - 17 Ph.D.s
 - Engineers, scientists, technical management
- 44,000 sq. ft. facility
- Class 100 clean room
- Several fully equipped laboratories
- CNC-equipped machine shop
- Equipment: SEM, TEM, AFM, SPM, UHV STM, numerous lasers, MEMS motion analyzer, electrical testing station





Nanotechnology vs. Molecular Nanotechnology

Nanotechnology

- Describes anything with characteristic dimensions at the nanometer (one billionth of a meter) scale.

Molecular Nanotechnology (MNT)

- Use of a controlled sequence of nanopositioning to perform mechanochemistry at exactly the reaction sites desired, flexibly manufacturing atomically precise products under software control.





Solutions Matrix

		Products	Licensing	Services	Alliances & Grants	
MATERIALS	CNT Integration Techniques and Composites	●	●	●	●	→
TOOLS	Microassembly Equipment	●		●	●	→
	Nano/Micro Research Equipment	●			●	→
	Voxel API Software	●	●		●	→
STRUCTURES	High-aspect Ratio Micromolding and Design for Assembly MEMS Processes		●	●	●	→
	Bio MEMS	●	●		●	→
	RF MEMS	●	●			→

Customers & Alliances




Stages of Growth

- **Stage One**
 - Develop technology
- **Stage Two**
 - Secure patents
- **Stage Three**
 - Market-driven product & licensing development
- **Stage Four**
 - Customer sales and licensing



Development Modes



Note:
NPD = New Product Development
LVD = Licensing Vehicle Development



Customers

Partial List






Alliances

Partial List

FROST & SULLIVAN

KEITHLEY

CARBON
NANOTECHNOLOGIES
INCORPORATED



THE UNIVERSITY OF
TEXAS
AT AUSTIN



University of
ColoradoSystem
CAMPmode

BSAC
Berkeley Sensor
& Actuator Center

NORTHWESTERN UNIVERSITY

HARVARD BUSINESS SCHOOL



Press

Partial List



The New York Times

electronic
design



Dallas Business Journal




The Dallas Morning News

Dallas-Fort Worth
TechBiz



- **Stage One**
 - Develop technology
- **Stage Two**
 - Secure patents
- **Stage Three**
 - Market-driven product & licensing development
- **Stage Four**
 - Customer sales and licensing





Intellectual Property

Zyvex patents


- 5 patents issued
- 43 patents pending
- 1 notification of allowance

Categories

- Molecular nanotechnology
- Microassembly technology
- Nanostructure process techniques
- Micro- and nanodevices
- Microconnector technology




Patent Filing Process





The Saleable IP Package



The Zyvex Approach: Materials




Development Goals

- Develop affordable, scalable, and superior CNT processing technologies
- Screen and develop practical CNT applications based on our CNT processing technologies




CNT Commercialization Map





CNT Value Chain



Nanotube Research Competence and IP Assets

External Endorsement & Support

- Prestigious NASA-funded research contract intended for achieving structurally-superior materials based on Zyvex proprietary CNT functionalization techniques.
- Customer-funded development for specific applications .

Key CNT Publications: November 2000 – present

- "Cyclodextrin-Mediated Soft Cutting of Single-Walled Carbon Nanotubes." *J. Am. Chem. Soc.*, 123, 6201-6202 (2001).
- "'Soft' way to cut nanotubes." *Chem. & Eng. News*, 79 (July 2, 2001), p. 23.
- "Room-Temperature Assembly of Directional Carbon Nanotube Strings." *J. Am. Chem. Soc.*, 124, 758-759 (2002).
- "Noncovalent Engineering of Carbon Nanotube Surfaces by Rigid Functional Conjugated Polymers." *J. Am. Chem. Soc.*, 124, 9034-9035 (2002).


Key CNT Intellectual Property

- Several U.S. Patents filed with international foreign rights secured.




Approaches of CNT Integration

[Other approaches]



Polymer Wrapping
(covalent-engineering)

[Zyvex Corporation]



Polymer Non-Wrapping
(non-covalent engineering)




CNT-Surface Solubility Engineering

Demonstrations

- A high yield non-covalent (low energy) process
- Allows increased functionality without loss of CNT properties

Applications

- Prerequisite for efficient CNT integration
- Electroless coating / EMI shield coating
- FED
- Highly dispersed nanotube / ceramic composites
- Highly dispersed nanotube / epoxy composites
- Highly dispersed nanotube / polymer composites



Cross-Section of 3% Wt. CNT Polycarbonate



Polymer-Non-Wrapping vs. Polymer-Wrapping

Functionalization of CNTs

Key Attributes	Polymer-Non-Wrapping	Polymer-Wrapping (Competitors)
Quantitative yield	High	High
CNT damage or loss of properties	No damage, No property loss	Surface Damaging, Carbon loss
Suitability for all SWNTs and MWNTs	Yes	Unsuitable for HiPco-SWNTs
Organic solubization for HiPco-SWNTs	> 50x Higher than competition	
Control of functional positions	Superior	Low control
Functionalization options	Highly versatile	Non-versatile



Polymer Composites

Accomplishments

- Double the strength of pure polymers
- 5 times increase in strain handling
- 1000 times greater conductivity than best published results of others

Goal: Better – Faster- Cheaper



Technology Comparison

View through 1mm of suspension of CNTs vs our solution of CNTs

- Our technology produces excellent dispersion in organic solvents.
- Compare the large visible clumps of CNTs visible in standard suspensions of CNTs with our solutions.
- We have produced CNT/polymer composites using this technology.



Suspension of 5 mg SWNT in 10 ml Organic Solvent



5 mg SWNT in 10 ml Chloroform using Zyvex Technology



Technology Comparison




Suspension of SWNT in Organic Solvent



Suspended in Chloroform using Zyvex Technology




Zyvex CNT Dispersion




SWNTs (5 wt%)/Polystyrene Composites



Electrical Conductivity



Dispersed SWNTs significantly increase the electrical conductivity.



The Zyvex Approach: Tools



SEM Nanomanipulator

Key Features

- Comprised of one platform and task-focused end-effectors
- 4 points of manipulation and characterization
- Compact / modular design
- Accommodates most SEM stations
- Quick-change of end-effectors



Under development

- Several end-effectors for increased tool functionality
- Compatibility/ Interchangeability w/ TEM

- 6 points of manipulation
- MEMS-actuator technology





Applications

- Electrical measurements
- Mechanical measurements
- Assembly and manipulation






S100 Nanomanipulator System



**The Zyvex Approach:
Structures**



Microgrippers




Microgripper with 36 μm opening

Patent 6,398,280



Microgrippers




Mounted to a manipulation station



Opening vs. Applied Voltage

Gripper opening with respect to the power-off position calculated as displacement of left arm + displacement of right arm



www.zyvex.com